



DOMITOP HF 24 - 30 E

FERELLA GOLD HF 24 - 30 MEL



- **Wall-Mounting Gas Boiler**
- **Airtight Chamber, Heating**



THIS DOCUMENT HAS BEEN PROVIDED BY

**heating**spares  
247.com

PLEASE VISIT [WWW.HEATINGSARES247.COM](http://WWW.HEATINGSARES247.COM) FOR FURTHER INFORMATION AND GENUINE PARTS & SPARES AT LOW PRICES

# TECHNICAL MANUAL

EDITION  
09i2002



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

<b>1. Technical characteristics and data .....</b>	<b>3</b>
1.1 Introduction .....	3
1.2 Dimensions and connections .....	4
1.3 General view and main components .....	8
1.4 Technical data table .....	10
<b>2. Product framework and internal components.....</b>	<b>11</b>
2.1 Hydraulic circuit - heating .....	11
2.2 Hydraulic circuit - tap water via external boiler .....	15
2.3 Gas circuit .....	17
2.4 Burner unit.....	21
2.5 Fume circuit.....	23
2.6 Electrical circuit .....	27
<b>3. Operation.....</b>	<b>30</b>
3.1 Operating principle .....	30
3.2 Operating diagram .....	31
3.3 Control panel .....	32
3.4 Adjustments.....	32
3.5 Operating parameter adjustment .....	33
<b>4. Troubleshooting .....</b>	<b>34</b>



# 1. TECHNICAL CHARACTERISTICS AND DATA

## 1.1 Introduction

Our appliance is a high-efficiency heat generator for central heating running on natural gas or LPG (configurable at the time of installation).

The boiler shell consists of a copper laminar exchanger whose particular shape guarantees high exchange efficiency under all operating conditions and an open-flue burner equipped with electronic ignition and ionization flame control.

The boiler is totally sealed off from the installation room: the air needed for combustion is drawn from outside and the flue gases are expelled by a fan. The boiler outfit moreover includes a variable speed circulator, expansion tank, safety valve, filler cock, air pressure switch, water pressure switch, temperature sensor and a safety thermostat.

Thanks to the control and adjustment system, unit operation is for the most part automatic. The power for heating is automatically governed by the control system according to the indoor characteristics, the characteristics of the building and of its location.

There are 5 LEDs on the control panel providing information on the unit's operating status.

### General Warnings



- Installation and maintenance must be carried out by professionally qualified personnel, according to current regulations and the manufacturer's instructions.
- Incorrect installation or poor maintenance can cause damage or physical injury. The manufacturer declines any responsibility for damage caused by errors in installation and use or by failure to follow the manufacturer's instructions given in the instructions manual..
- Before carrying out any cleaning or maintenance operation, disconnect the unit from the electrical power supply using the switch and/or the special cut-off devices.

#### Certification



The CE marking demonstrates that Ferrolì gas units conform to the requirements contained in the applicable European directives.

In particular, this unit complies with the following EU directives:





- Gas Appliance Directive 90/396 assimilated with Italian Presidential Decree DPR 15.11.96 no. 661
- Efficiency Directive 92/42 assimilated with Italian Presidential Decree DPR 15.11.96 no. 660
- Low Voltage Directive 73/23 (amended by 93/68)
- Electromagnetic Compatibility Directive 89/336 (amended by 93/68) assimilated with Italian Presidential Decree DPR 15.11.96 no. 615



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

**1.2 Dimensions and connections**  
**Domitop HF 24 E version**

**Top view**





**Key**

- 1 System delivery
- 2 Gas inlet
- 3 System return
- 4 System filler inlet

**Bottom view**

## Ferella Gold HF 24 MEL version

Top view



Top view

- 1 System delivery
- 2 Gas inlet
- 3 System return
- 4 System filler inlet




Bottom view



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

**Domitop HF 30 E version**

**Top view**







**Bottom view**

**Key**

- 1 System delivery
- 2 Gas inlet
- 3 System return
- 4 System filler inlet

## Ferella Gold HF 30 MEL version

Top view



**Key**


- 1 System delivery
- 2 Gas inlet
- 3 System return
- 4 System filler inlet

Bottom view



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

**1.3 General view and main components  
HF 24 E/MEL version**



**Key**

- 5 Airtight chamber
- 7 Inlet
- 10 System delivery
- 11 System return
- 14 Safety valve
- 16 Fan
- 19 Combustion chamber
- 20 Burner assembly
- 21 Main nozzle
- 22 Burner
- 26 Combustion chamber insulation
- 27 Copper exchanger
- 28 Fume manifold
- 29 Fume outlet manifold
- 32 Heating circulator
- 34 Heating temp. sensor
- 36 Automatic air vent
- 43 Air pressure switch
- 44 Gas valve
- 49 Safety thermostat
- 50 Heating thermostat
- 56 Expansion tank
- 63 Heating temperature adjustment
- 74 Heating system cock
- 81 Ignition electrode
- 82 Detection electrode
- 84 1st gas valve operator
- 85 2nd gas valve operator
- 98 Off-On-Reset switch
- 114 Water pressure switch
- 145 Water gauge
- 187 Fume diaphragm


**DOMITOP - FERELLA GOLD version**



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL



**HF 30 E/MEL version**



**Key**

- 5 Airtight chamber
- 7 Inlet
- 10 System delivery
- 11 System return
- 14 Safety valve
- 16 Fan
- 19 Combustion chamber
- 20 Burner assembly
- 21 Main nozzle
- 22 Burner
- 26 Combustion chamber insulation
- 27 Copper exchanger
- 28 Fume manifold
- 29 Fume outlet manifold
- 32 Heating circulator
- 34 Heating temp. sensor
- 36 Automatic air vent
- 43 Air pressure switch
- 44 Gas valve
- 49 Safety thermostat
- 50 Heating thermostat
- 56 Expansion tank
- 63 Heating temperature adjustment
- 74 Heating system cock
- 81 Ignition electrode
- 82 Detection electrode
- 84 1st gas valve operator
- 85 2nd gas valve operator
- 98 Off-On-Reset switch
- 114 Water pressure switch
- 145 Water gauge
- 187 Fume diaphragm

**DOMITOP - FERELLA GOLD version**



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

### 1.4 Technical data table

DOMITOP - FERELLA GOLD		24 KW		30 KW	
Powers		Pmax	Pmin	Pmax	Pmin
Heating Power (Net Heat Value - Hi)	kW	25.8	11.2	33.1	14.5
	kcal/h	22,200	9,900	28,500	12,500
Heating Power (Gross Heat Value - Hi)	kW	28.7	12.4	36.8	16.1
	kcal/h	24,700	10,700	31,600	13,800
Useful heating power 80°C - 60°C	kW	23.3	9.7	30.0	12.7
	kcal/h	20,000	8,300	25,800	10,900
Gas supply		Pmax	Pmin	Pmax	Pmin
Natural Gas main nozzles (G20)	mm	12 x 1.30		16 x 1.25	
Natural Gas supply pressure (G20)	mbar	20.0		20.0	
Pressure at Natural Gas burner (G20)	mbar	11.8	2.5	11.8	2.5
Natural Gas delivery (G20)	nm <sup>3</sup> /h	2.73	1.19	3.50	1.53
LPG main nozzles (G31)	mm	12 x 0.77		16 x 0.75	
LPG supply pressure (G31)	mbar	37.0		37.0	
Pressure at LPG burner (G31)	mbar	36.0	7.0	35.5	7.0
LPG burner (G31)	Kg/h	2.00	0.87	2.57	1.13
Heating					
Maximum working temperature in heating	°C	90		90	
Maximum working pressure in heating	bar	3		3	
Safety valve	bar	3		3	
Minimum working pressure in heating	bar	0.8		0.8	
Expansion tank capacity	litres	8		10	
Expansion tank pre-filling pressure	bar	1		1	
Boiler water content	litres	1.5		1.7	
Dimensions, weights connections					
Height	mm	760		760	
Width	mm	460		460	
Depth	mm	272		363	
Weight with packing	kg	35		45	
Gas system connection	inches	1/2"		1/2"	
Filling system connection	inches	1/2"		1/2"	
Heating system connection	inches	3/4"		3/4"	
Electrical power supply					
Max electrical power absorbed	W	125		125	
Power voltage/frequency	V/Hz	220/50		220/50	
Electrical protection rating	IP	44		44	




## 2. PRODUCT FRAMEWORK AND INTERNAL COMPONENTS

### 2.1 Hydraulic circuit – heating

#### Hydraulic diagram for heating

When there is a call for heat, the room thermostat or control system make the burners ignite and the circulation pump come into operation. The heat contained in the products of combustion is transferred to the water by the system via the exchanger. For more details on the operating logic, refer to chap.3.






DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

**Circulator (230v/50Hz)**

Located on the heating circuit return, it is connected directly to the exchanger via special forks and connected to the system via a threaded brass section. It has three delivery/head levels (see diagram). Changing the delivery/head changes the speed of the water flowing through the boiler exchanger and as a result the temperature difference ( $\Delta T$ ) between heating delivery and return. Clearly, increasing the delivery of the circulator decreases  $T$  and vice versa. If it is not used for a long time, the impeller might "jam" due to debris in the water. With the front screw it is possible to access the impeller, which can be freed with the aid of a screwdriver. The connection to the expansion tank and the air separator is installed on the pump casing.




**Checks**

If the pump doesn't work:

- Check that the impeller is free to turn by turning the screw on the front with a screwdriver.
- Check that both the card and the pump connection are powered.
- If there is no power supply, check the card.
- If there is power, change the pump.


Key

- 1 - 2 - 3 = Pump selector position
- A = Losses of head 24kW version
- B = Losses of head 30kW version



**Air separator**

This is used to expel the air in the heating circuit automatically and is located on the pump casing. It is normally accessible either via the fork or by simply unscrewing it from its seat.



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL



**Expansion tank**

It is connected to the pump casing via a pipe with a fork connection. On the 24kW version, it is located above the pump, while on the 30kW version it is located behind the exchanger, inside the frame. The expansion tank contains a diaphragm in contact, on one side, with the system water and, on the other side, with the air under pressure (pre-loaded to 1 bar) inside the tank. By the expansion of the diaphragm and ensuing compression of the air, the tank compensates for the thermal expansion of the water in the heating system.

24kW  
8-litre version





30kW  
10-litre version



**Exchanger**

The exchanger is a copper laminar assembly. It comprises a thickly finned portion and four circular pipes connected together in series. The water exchanges directly with the combustion gases and makes the system safe via a safety thermostat (100°C) and the limit thermostat (88°C). Due to its shape and design, the heat gets evenly distributed over all the finning, with consequent benefits in terms of exchange efficiency and the life of the exchanger. A special surface treatment protects the exchanger against oxidation and corrosion.





## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL

### **Hydraulic unit**

This is a single piece of brass to which the exchanger delivery is connected for ease of access. It accommodates a number of safety and adjustment components.

The hydraulic unit includes:

- safety valve
- water pressure switch
- heating sensor
- filler cock
- check valve




### **Water pressure switch**

It ensures a minimum pressure for the system. It is normally open (NO) and closes the contact when the pressure exceeds 0.5 bar. It works on low voltage.



### **Safety valve**

It opens if the pressure exceeds 3 bars, making boiler operation safer and protecting it against overpressure. You are strongly recommended not to use this valve to drain the system; once open, dirt could remain inside it, preventing it from closing completely.




### **Check valve**

It ensures the filling system flows only in one direction and remains airtight along with the cock.



### **Filler cock**


The boiler has a 1/2" connection on the right-hand side of the heating delivery for filling the system. It is not fitted on the boiler for some markets such as the British and Belgian ones.



## 2.2 Hydraulic circuit - tap water via external boiler

### Hydraulic diagram for tap water

The HF is a boiler for heating only. However, if required, the HF has a special kit for connecting the boiler for tap water, too, via an external boiler. The solution shown in the hydraulic diagram has a three-way diverter valve and a sensor for the external boiler. The kits also contain connection pipes that vary depending on the model. The tap water temperature can be adjusted by inserting the knob (included in the kit) in the control panel (D).



### Key

- |    |                      |     |                        |
|----|----------------------|-----|------------------------|
| 5  | Airtight chamber     | 50  | Heating thermostat     |
| 7  | Inlet                | 56  | Expansion tank         |
| 10 | System delivery      | 74  | Heating system cock    |
| 11 | System return        | 81  | Ignition electrode     |
| 14 | Safety valve         | 82  | Detection electrode    |
| 16 | Fan                  | 84  | 1st gas valve operator |
| 20 | Burner assembly      | 114 | Water pressure switch  |
| 29 | Fume outlet manifold | 187 | Fume diaphragm         |
| 32 | Heating circulator   | A   | Boiler                 |
| 34 | Heating temp. sensor | B   | External boiler        |
| 43 | Air pressure switch  | C   | Boiler expansion tank  |
| 44 | Gas valve            | D   | Tap water inlet        |
| 49 | Safety thermostat    | E   | Tap water outlet       |
|    |                      | F   | Heating circuit        |









# DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL


## Electrical and plumbing connections

The terminal block for the electrical connections is designed for hooking up the diverter valve and the sensor. It is necessary to take out the 1.8 KOhm resistor on the probe connection whose job was to simulate a virtual, always-satisfied boiler.

## Boiler connection kit assembly instructions




- Connect the pipes and 3-way valve as shown in Fig. 1.
- Make the electrical connection to the terminal block A (Fig. 2) as shown in the diagram Fig. 3.
- Connect the 3-way valve (Ref. 95).
- Connect the boiler sensor (Ref. 155).
- Take out the resistor between terminals 3 and 4.
- Open the instrument panel, take out the plug C (Fig. 4) and insert the knob D (Fig. 5) to adjust the tap water temperature.





## 2.3 Gas circuit

### Gas circuit diagram



#### Key

- 5 Airtight chamber
- 7 Inlet
- 10 System delivery
- 11 System return
- 14 Safety valve
- 16 Fan
- 20 Burner assembly
- 29 Fume outlet manifold
- 32 Heating circulator
- 34 Heating temp. sensor
- 43 Air pressure switch
- 44 Gas valve
- 49 Safety thermostat
- 50 Heating thermostat
- 56 Expansion tank
- 74 Heating system cock
- 81 Ignition electrode
- 82 Detection electrode
- 84 1st gas valve operator
- 114 Water pressure switch
- 187 Fume diaphragm
- 222 Copper exchanger



## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL


### Gas valve

It supplies gas to the nozzles between a minimum and maximum pressure. For the valve to work correctly, it is necessary for the pressure upstream from it to be stable and suited to the type of gas being used, while the valve will supply a regular pressure to the nozzles. The gas valve contains two operators. The function of the first one is to open or close, while the task of the second one is to modulate the capacity according to the system's requirements. The signal comes from the card (X6-1/2/3/4) and is in the form of continuous voltage. The first operator receives fixed voltage that may be between 80 and 110V DC, for the second operator the voltage will vary between 25 and 54V DC according to the need of the main card.

### Checks

If the valve doesn't work:

- Check there is gas, and that gas comes out of the valve by means of screw B.
- If there is no gas, you must check there is voltage at the operators. This makes it possible to understand whether the problem lies with the valve (there is voltage at the operators) or with the card (there is no voltage at the contacts X6-1/2/3/4).



### Modulation

The control system governs its boiler capacity so as to keep the delivery temperature constant in accordance with the settings on the control panel. The nozzle gas pressure is modulated by the valve and specifically via the 2nd operator. The card provides a change in continuous voltage (between 25 and 54 VDC) according to the difference between the delivery temperature and the set point.

### Checks

Modulation can be checked in three ways:

- Visually, by checking the flame.
- Using a pressure gauge to check the gas pressure downstream from the valve.
- Checking the voltage of the second operator on the card (X6, 1/2). This is the most effective method in some situations. With this test, it is possible to understand whether the problem lies with the valve or with the card.



Note that with very low pressure upstream from the valve, opening the valve may be slow and the boiler could shut down due to failed ignition.



DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL




**Adjusting burner pressure**

Since this unit has flame modulation, there are two fixed pressure settings: the minimum and maximum, which must be as stated in the technical data chart according to the type of gas.

- Connect a suitable pressure gauge to pressure point "B" downstream from the gas valve.
- Disconnect the pressure compensation tube "F".
- Take off the protective cap "C".
- Set the potentiometer P3 (on the control card) to minimum (clockwise).
- Run the boiler in heating mode.
- Adjust the minimum pressure with the screw "D", clockwise to decrease it and anticlockwise to increase it.
- Set the potentiometer P3 to maximum (anticlockwise).
- Turn on the "TEST" function by temporarily bridging X5.
- Adjust the maximum pressure with the screw "E", clockwise to increase it and anticlockwise to decrease it.
- Reconnect the pressure compensation tube "F".
- Put the protection screw "C" back in.
- Disconnect the test jumper.




**N.B. The test lasts 5 minutes**

 After checking or adjusting the pressure, it is mandatory to seal the adjustment screw with paint or a specific seal.

**Key**

- A Pressure point upstream
- B Pressure point downstream
- C Protection screw
- D Minimum pressure adjustment screw
- E Maximum pressure adjustment screw
- F Pressure compensation tube






## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL


### **Gas supply conversion**

The unit can function with either Natural Gas or LPG and is factory-set for use with one of the two gases, as clearly shown on the packing and on the unit's dataplate. Whenever a different gas to that for which the unit is preset has to be used, a conversion kit will be required, proceeding as follows:

- 1 Replace the nozzles at the main burner, inserting the nozzles specified in the technical data table, according to the type of gas used.
- 2 Adjust the burner minimum and maximum pressures, setting the values given in the technical data chart for the type of gas used.
- 3 Move the jumper JP02 on the card, as shown in the diagram:



- 4 Apply the sticker, contained in the conversion kit, near the dataplate as proof of the conversion.




## 2.4 Burner unit

### Operation

The burner unit comprises a manifold and 12/16 nozzles (depending on the capacity), the burner mount, electrodes and the burner assembly.


### Manifold - nozzles

The valve sends gas at a suitable pressure to the manifold, which homogeneously distributes the gas to the single burner stages at the nozzles. It is secured directly to the burner mount. Its positioning must be exact since it affects the air/gas mixture. In addition, the threaded holes forming the seat of the nozzles must be aligned with the respective Venturi tube of the burner. If it were not so, the air/gas mixture would be wrong and there would be poor combustion with an unstable flame. The nozzles are made of brass and machined extremely precisely for their dimensions. There is a seal between the nozzles and the manifold.



### Ignition electrode


The ignition electrode is made of a metal alloy (Kanthal) that withstands high temperatures and oxidation. Its base is composed of a ceramic composite of glazed alumina whose purpose is to protect and electrically insulate it. Once the ignition procedure begins, the card powers the electrode with a pulsating voltage of a few kV, a series of electrical discharges is set off between the electrode and the head of the burner (set at a distance of 3.5 mm). Clearly, these sparks are the trigger for the air-gas mixture. It is important for the distance between the electrode and the burner head to be 3 - 4 mm and the discharge to be made at the centre.



### Checks

If there is no discharge:

- Check whether the boiler shuts down, in which case check the connection of the electrode to the card or whether it discharges at other points; if necessary, check the safety thermostat and the card.
- If the boiler does not shut down and the fan keeps on working, check the air pressure switch.
- If there is a discharge, but no ignition and after 10 seconds the boiler shuts down, check the gas valve and, if necessary, the card.
- If there is a discharge and then a flame, but the boiler still shuts down after 10 seconds, check the detection electrode and its connection.





## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL



### Detection electrode

Made of the same material as the ignition electrode, it is set 11 mm from the burner head. Combustion causes the flame atmosphere to ionize, making it conductive. Thanks to the mass of the burner, making a suitable potential with the electrode produces a flow of direct current on it. For our cards, it is necessary to have an ionizing current of at least  $0.5 \mu\text{A}$  to detect a flame. A mean signal is normally obtained of approximately  $2 \mu\text{A}$ .



### Burner assembly


The burner assembly is composed of 12 or 16 burner stages. Each stage is composed of two pressed steel half bearings, with a suitably cut stainless steel head. Gas enters at the bottom of the stage. Thanks to the special Venturi-tube shape of the bottom portion of the stage, the gas "injected" by the nozzle carries with it the primary air needed for combustion. The air-gas mixture thus formed inside the stage is evenly distributed on the burner head. Combustion takes place homogeneously over the entire length of the single stages, with the contribution of the secondary air from the bottom of the burner mount and from the combustion chamber itself. The set of stages in operation forms a single belt of flame, light blue in colour, whose size varies according to the nozzle gas pressure, that is the boiler capacity modulation.



## 2.5 Fume circuit

### Fume deflector and manifold

All forced-flow boilers have a fume deflector above the exchanger whose main task is to make the secondary air crossing the burners uniform, making the flame homogeneous and stable. The fumes then reach a fume manifold whose job is to make them move on to the fan.





### Airtight chamber

Its task is to isolate the products of combustion from the area surrounding the boiler. The airtight chamber contains all the components involved in the fume routing. The wires and pipes coming out of its lower portion are insulated with silicone seals, while its upper portion is fitted for hooking up with the flues. The cover is sealed off with a porous plate and is fitted with two plugs for using a probe to analyse the fumes and combustion air.



### Fan and pressure switch points

Powered at 230V/50Hz by the card (X6 - 7/8), the fan has the job of expelling the products of combustion from the fume chamber. A plate is normally placed above the exchanger to act as a deflector, make the incoming air from the bottom of the burner uniform, make the flame stable and obtain the required air/gas ratio. In order to make sure the fan works properly, there are two pressure points inside it. The first one detects a "static" pressure signal that is positive, the second one detects a "dynamic" pressure signal via an appropriate "Venturi tube", which is negative. With the difference in pressure detected by the two test points it is possible to check whether the fumes are adequately evacuated.





## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL

### Air pressure switch


This is used to check whether the fumes are adequately evacuated. The pressure switch compares the static and dynamic signals coming from the pressure test points on the fan according to the figure. The pressure switch is connected to the card and is normally open (see diagram). Before the card initiates the ignition procedure (opening the valve, etc.), you must make sure that the fan works properly and that the air pressure switch ensures this by closing its contacts. This happens if the difference in pressure is  $165 \pm 15 \text{ Pa}$ . So the signal must be at least  $180 \text{ Pa}$ . To open its contacts again, the difference in pressure must drop under  $150 \pm 13 \text{ Pa}$ . To perform checks on contact opening and closing, it is always recommended to check directly on the card (X5 - 3/4).

### Checks

It is necessary to check:

- Whether the electrical connections are correct.
- Whether the pressure test point pipes are clean and contain no condensation water.
- That the signal is open when the fan is not working.
- That the pressure is at least  $180 \text{ Pa}$  and that above this pressure the pressure switch closes its contacts.
- If the signal is low, it is necessary to check that the fume diaphragm is correct, the fan has  $230 \text{ V}$ , the pressure test points are properly inserted and the Venturi tube has no burrs of any kind. Lastly, check that the ends of the pipes are not obstructed.

N.B. The pressure difference must be measured with the airtight chamber closed. The pressure gauge connections can come out through the hole, which is closed by a silicone plug, on the front of the cover.








### Fume ducts

The unit is "type C" with an airtight chamber and forced draught, the air inlet and fume outlet must be connected to one of the following extraction/suction systems. With the aid of the tables and methods of calculation indicated, before commencing installation, it is first necessary to check that the fume ducts do not exceed the maximum permissible lengths. The current standards and local regulations must be observed.

 This C-type unit must be installed using the fume exhaust and suction ducts supplied by FERROLI S.p.A. in accordance with UNI-CIG 7129/92. Failure to use them automatically forfeits all warranty and liability of FERROLI S.p.A.

### Diaphragms

Boiler operation requires fitting the diaphragms supplied with the unit as instructed in the following tables. As the resistance of the fume ducts changes, the diaphragms make it possible to keep the combustion parameters (CO<sub>2</sub>, etc.) within the optimum operating range. Note that with low-resistance fume ducts, a high-resistance diaphragm (small hole diameter) is used and vice versa.

#### Choosing the diaphragm using coaxial pipes


Type	Length up to:	Diaphragm to use	
		HF 24	HF 30
Coaxial 60/100	1 bend + 1 metre	50 mm	52 mm
	1 bend + 3 metres	No diaph.	No diaph.
Coaxial 80/125	1 bend + 3 metres	45 mm	50 mm
	1 bend + 4 metres	50 mm	No diaph.
	1 bend + 5 metres	No diaph.	No diaph.

#### Choosing the diaphragm using separate pipes



Pipe length calculated in linear metres		Diaphragm to use	Pipe length calculated in linear metres		Diaphragm to use
Min	Max		HF 24	HF 30	
0 m	10 m	45 mm	0 m	10 m	47 mm
10 m	20 m	47 mm	15 m	30 m	50 mm
20 m	35 m	50 mm	30 m	40 m	52 mm
35 m	45 m	No diaph.	40 m	45 m	No diaph.

### Changing the diaphragm

If inserting or changing a diaphragm, it is necessary to remove the fan assembly, take out the fume coupling 1 and insert the required diaphragm 2.



Boilers are fitted as standard with the smallest diaphragm in the series. Before inserting the fume outlet pipe, it is therefore necessary to check there is the right diaphragm (when it is to be used) and that it is correctly positioned.






DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

**Calculation example**

Here we give an example of the calculation for a separate fume outlet. We recommend inserting a condensate trap on long vertical sections to prevent condensation getting onto the burner and damaging it. If monitoring the condensate trap is not guaranteed, it must be fitted with a suitable drain pipe and air trap, which in its turn must be appropriately connected to a suitable drain.



Ref.	No.Pieces	Description	Equivalent loss
1	1	Air bend Ø80	1.5 m
2	1	Horizontal air pipe Ø80	1.0 m
3	1	Windproof end piece	2.0 m
4	1	Condensate collection cup coupling	3.0 m
5	36	Vertical fume pipe Ø80	36.0 m
6	1	Outlet flue + coupling	4.0 m
<b>Total</b>			<b>47.5 m</b>

DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL




## 2.6 Electrical circuit


### Electrical terminal board

Follow the instructions given in the figure to access the electrical connection terminal board.

The layout of the terminals for the various connections is given in the wiring diagram.



### Wiring diagram



**Key**

- |    |                            |    |                                |     |                       |
|----|----------------------------|----|--------------------------------|-----|-----------------------|
| 16 | Fan                        | 50 | Limit thermostat               | 98  | Switch                |
| 32 | Heating circulator         | 72 | Room thermostat (not supplied) | 101 | Electronic card       |
| 34 | Heating temperature sensor | 81 | Ignition electrode             | 114 | Water pressure switch |
| 43 | Air pressure switch        | 82 | Detection electrode            | 155 | Boiler sensor         |
| 44 | Gas valve                  | 95 | Diverter valve                 | 175 | Transformer           |
| 49 | Safety thermostat          |    |                                | R   | Resistance 1.8 Ohm    |

N.B. Respect the phase and neutral connections




## DOMITOP HF 24 - 30 E FERELLA GOLD HF 24 - 30 MEL

### **Main electronic card**

The electronic card is a Honeywell PMF03: part of the card works on low voltage (24V) and the remainder on 230V (see diagram) and it is fitted with a fuse (2A). Part of the card is used to control ignition, so it is hooked up to the detection and ignition electrodes and the safety thermostat. There are loads and controls common to the card that have already been described, such as:

- Pump.
- Fan.
- Gas valve.
- Air pressure switch.

There remain some components described hereunder.



### **Ignition + detection electrode, see chap. 2.4 Burner Unit**


### **Safety thermostat**

X6 - 5/6 has a thermostat with gold contacts that opens if the temperature exceeds 100°C. Connected directly to the ignition and main card, when it opens it cuts off the power supply to the valve directly, shutting down the boiler. It is located on the left-hand side of the exchanger in an appropriate flat seat.



### **Limit thermostat**


Connected on the main card X4 - 6/7, it is a thermostat with silver contacts that opens if the temperature exceeds 88°C. It requires no manual resetting and closes the contacts again if the temperature falls under 70°C. It is located on the right-hand side of the exchanger in an appropriate flat seat.






**Heating temperature probe**

These are NTC sensors that increase their resistance as the temperature decreases and are connected directly to the main card X4-24V(12-13). The sensor performs the antifreeze function too.



Temperature (°C)	Resistance (K Ohm)
100	0,68
90	0,92
80	1,25
70	1,7
60	2,5
50	3,6
40	5,3
30	8
25	10
15	15,6
5	25,3





## 3. OPERATION

### 3.1 Operating principle

When there is a call for heating, the circulator and fan start working; then the air pressure switch enables the control and safety unit to ignite the burner. Via the electronic flame modulation system, the boiler capacity is gradually metered till it reaches the set delivery temperature. If the power needed for the heating plant is lower than the minimum boiler power, when the delivery temperature exceeds the setting of 6°C, the burner switches off and the electronic system enables re-ignition only after another 2 minutes. On reaching the set ambient temperature (room thermostat), the burner switches off and the circulator keeps on working for another 6 minutes to enable better heat distribution throughout the system.

#### **Test function**

Bridging the terminals of connector X5 turns on "Test" operation. In this mode the boiler works as in heating mode, but idle time and modulation are turned off. The test lasts 5 minutes.

#### **Post-circulation**

After the call for heating, the circulator performs "post-circulation" for approximately 6 minutes to prevent thermal inertia and balance the system boiler temperature.

#### **Circulator anti-locking**

If not used for 24 h, the circulator is turned on for a few seconds to prevent it locking due to an extended stoppage during summertime operation.

#### **Gradual starting on heating** (gradual increase in heating temperature)

The time to reach the maximum heating temperature is 5 minutes.

#### **Limit thermostat**


The 88°C limit thermostat coming on causes the burner to switch off momentarily via the ignition unit and the heating circulator to start up.

#### **Antifreeze protection**

The antifreeze function is turned on by the heating temperature sensor when the temperature falls under 5°C. In this phase, both the burner and the circulator start working. When the temperature reaches 15°C, the burner switches off while the circulator keeps on working for another 6 minutes.




### 3.2 Operating diagram





DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL

### 3.3 Control panel



LED		ITEM	DESCRIPTION
		A	OFF/ON/RESET switch
a		B	Heating temperature setting
b		C	Water gauge
d		D	Boiler temp. adjustment (with optional kit)
e		E	Arrangement for clock

### 3.4 Adjustments

#### **Room temperature adjustment (with room thermostat on)**

Using the room thermostat or remote control, set the temperature desired in the rooms. Controlled by the room thermostat, the boiler lights and heats the system water to the set system delivery setpoint temperature. The generator turns off when the desired temperature in the rooms is reached.

If the room thermostat or the remote control are not installed the boiler will keep the system at the set system delivery setpoint temperature.

#### **System temperature adjustment**

With knob "B" on the control panel we can set the required system temperature. To prevent localized condensation on the fume circuit, we recommend a minimum temperature of 60°C.

#### **Hot water temperature adjustment**

With knob "D" on the control panel we can set the tap water temperature from 40°C to 55°C (with optional kit).

#### **Summer/Winter selection**

Setting the adjustment potentiometer "B" to minimum (☼), the boiler works on "Summer".

#### **Adjusting the heating Δt by changing the circulator delivery-head**

The temperature difference Δt (difference between the system delivery and return heating water temperatures) must be under 20°C and is obtained by changing the circulator delivery-head with its variable speed device (or switch).





## 3.5 Operating parameter adjustment

### Boiler parameter adjustment

- P1** Temperature adjustment potentiometer.  
Controls the heating delivery temperature from 30°C to 85°C.  
The minimum position selects "Summer" operation.
- P3** Heating capacity adjustment potentiometer.
- P4** Potentiometer to adjust the burner gas pressure in the ignition phase.  
The maximum ignition time is 10 sec.  
The ignition curve should be regulated taking account of the type of burner and fuel used (natural gas or LPG).
- P5** Minimum pressure adjustment potentiometer.  
The potentiometer P5 is to be used if it is necessary to adjust the minimum current to the second coil of the gas valve.  
This adjustment makes it possible to increase the gas valve minimum opening pressure electrically. The potentiometer P5 is used when the mechanical minimum of the gas valve does not enable adequate adjustment.

### Jumper operation

**Jumper JP01:** If using an external boiler for the tap water

JP01	Inserted	3-way valve system
	Not inserted	Not contemplated

The boilers are made with JP01 not inserted

**Jumper JP02:** Boiler operation with natural gas or LPG


JP02	Inserted <input type="checkbox"/>	Natural gas operation
	Not inserted <input type="checkbox"/>	LPG operation



## 4. Troubleshooting

### Flow Diagram 1


#### Checking Electric Power Supply - System Pressure and Antifreeze Protection






### Flow Diagram 2

#### Checking Heating Operation



### Flow Diagram 3

#### Controllo Ventilatore/Circuito Fumi






DOMITOP HF 24 - 30 E  
FERELLA GOLD HF 24 - 30 MEL


**Flow Diagram 4**

**Checking ignition**



**Flow Diagram 5**

**Check the Modulation of the Hot Water and Heating**











37047 SAN BONIFACIO - VR - ITALY

tel. 045/6139411 - tlx 480172

fax 045/6100233-6100933

cod. 354M007/0